



The Elumenati LLC

1924 S. Hilbert St.

Milwaukee WI 53207


www.elumenati.com

EZ3 Window Management


Quick overview

Checking the state of each ez3 window


For WorldViewer, hover the mouse over WorldViewer icon in the taskbar, a preview window will popup:



For ez3 windows (dome screen, end user control windows, etc.), hover the mouse over ez3 icon, a preview with all active ez3 display windows will popup:



The state for each ez3 window will be displayed inside the popup window preview.



Each state icon and its tooltip:



Press CTRL+ENTER to set window to fullscreen.



Window in fullscreen, press CTRL+ENTER to restore to original size.



Press CTRL+ALT+ENTER to set window always on top.



Window is set to always on top, press CTRL+ALT+ENTER to remove this property.



Reset To Primary Monitor (CTRL+SHIFT+ENTER).



and are toggle states from the same button, meaning the fullscreen state for that specific window is changed by pressing the same button again.



and are also toggle states from the same button, meaning the always on top state for that specific window is changed by pressing the same button again.




is a stateless button, when you click it it will reset that window fullscreen state and center it in the primary monitor. This is useful if a window position is accidentally moved and you need to recover it to then reposition correctly.



Using Icons to control ez3 state

Fullscreen state toggle






When  is displayed, ez3 window is set to windowed mode, meaning it has a taskbar with minimize, maximize and close buttons. Drag the ez3 window to the desired



monitor/projector and click , state icon will change to  and the ez3 window becomes fullscreen with no taskbar visible on that monitor/projector. To remove fullscreen




state, click  and it will revert back to  exiting fullscreen mode.





Always on top state toggle





When  is displayed, ez3 window will behave like any other window. Windows behind that are activated will be set on top. Meaning that our ez3 window could be obscured by other windows (explorer, chrome, etc).



Click  and it will transition to , now ez3 window is set to be always on top. Meaning that even if another window behind is selected, it won't obscure (be set to top) the current one. This is useful for end user control screen or kiosk style operation.




To revert back click  and it will transition to  restoring the normal window behavior.



Reset to primary



Click  to bring the ez3 window back to the primary monitor, it will also remove fullscreen status from it.

Using keyboard shortcuts to control ez3 state

First step to use keyboard shortcuts is being sure that the **correct window** is selected. To avoid changing states from other windows be sure **to mouse click (or with touch input, touch)** on the window that is going to be changed.

Fullscreen state toggle

When an ez3 window is in windowed mode, move it to the correct monitor/projector and press the keyboard combination CTRL+ENTER. That will set fullscreen on that monitor/projector. Pressing CTRL+ENTER on a fullscreen ez3 window will revert it back to windowed mode.

Always on top state toggle

Press CTRL+ALT+ENTER and it will set/unset "always on top" state, depending on the previous state.

Reset to primary

Press CTRL+SHIFT+ENTER to reset ez3 window back to primary monitor, it will also remove fullscreen status from it.

End user safe Omnity Ez3 menu (for EG setting remote GUI, IP changes, etc.)

Press CTRL+SHIFT+E to access ez3 Omnity menu.